PARTS GUIDE

Hunter

STOP Using this Parts Guide, make sure all parts are included in the box.

If parts are missing, DO NOT RETURN THIS ITEM TO THE STORE, call 888-855-8300 for assistance.


THIS PARTS GUIDE IS FOR REFERENCE ONLY.
REFER TO THE INSTALLATION MANUAL FOR FULL ASSEMBLY INSTRUCTIONS.

Hardware
(Drawn to Scale)

- x 1 Low Profile Washer
- x 2 3" Wood Screw
- x 5 Flat Washer
- x 3 1.5" Wood Screw
- x 3 Locking Screw
- x 4 Canopy Screw
- x 1 Setscrew
- x 4 Mounting Isolator
- x 11 Screw, Blade Iron Armature
- x 16 Screw, Blade Assembly
- x 16 Blade Grommet
- x 1 Balancing Kit
- x 4 Wire Connector
- x 3 Screw, Switch Housing Assembly
- x 10 Thumbscrew
- x 3 Screw, Machine, 6-32


Fan Parts
(Not Drawn to Scale)

- Hanger Bracket Assembly
- Blade Assembly
- Switch Housing Assembly

Parts List

Item Name	Model # / Asm. Dwg. # / Finish / Qnty	27436 / 93026-01 / White / Part #	27430 / 93026-04 / Antique Brass / Part #	27431 / 93026-05 / Brushed Nickel / Part #
* Hanging System Kit	1	94330-03	94330-05	94330-09
Ceiling Plate				
Canopy				
Canopy Trim Ring				
Hanger Ball / Downrod Assembly				
Setscrew				
Low Profile Washer				
Canopy Screw				
Wood Screw 1.5"				
Wood Screw 3"				
Flat Washer				
Mounting Isolator				
* Screw, Low Profile				
Light Kit Assembly	1	99680-03	99680-05	99680-09
Blade Iron Set	1	92803-07	92803-07	92803-07
Blade Set	1	75516-30	75516-28	75516-35
Screw, Blade Iron Armature	11	63755-05	63755-05	63755-05
Hardware Kit	1	93026-00-860	93026-00-863	93026-00-864
Blade Grommet				
Blade Assembly Screw				
Screw, Machine, 6-32				
Wire Connector				
Screw, Switch Housing Assembly				
Balancing Kit	1	65666-01	65666-01	65666-01
Switch Housing, Lower, Alternate	2	93598-01	93598-01	93598-01
Switch Housing Cover, Alternate	1	73853-01	73853-01	73853-01
Switch Housing Cover, Alternate	1	73854-01	73854-01	73854-01
Thumb Screw	10	03077-08	03077-08	03077-08
Globe/Shade	3	73560-14	73560-13	84884-03

GUIDE DE PIÈCES





Hunter

À l'aide de ce guide de pièces, vérifier que toutes les pièces sont dans la boîte. S'il manque des pièces, NE PAS RETOURNER CET ARTICLE AU MAGASIN, appeler le 866-268-1936 pour de l'aide. CE GUIDE DE PIÈCES EST POUR RÉFÉRENCE UNIQUEMENT. SE REPORTER AU MANUEL D'INSTALLATION POUR DES DIRECTIVES COMPLÈTES DE MONTAGE.

Quincaillerie d'installation
(à l'échelle)

- x 1 Rondelle profil bas
- x 2 3" Vis à bois
- x 5 Rondelle plate
- x 3 1.5" Vis à bois
- x 3 Vis de blocage
- x 4 Vis de pavillon
- x 1 Vis de fixation
- x 4 Isolateur de fixation
- x 11 Vis, armature de fer de pale
- x 16 Vis de montage de pale
- x 16 Œillet de pale supérieur
- x 1 Trousse d'équilibrage
- x 4 Capuchon de connexion
- x 3 Vis, ensemble du boîter d'interrupteur
- x 10 Vis papillon
- x 3 Vis à métal, 6-32

Pièces du ventilateur
(pas à l'échelle)

- Ensemble de fixations de suspension
- Montage de pale
- Ensemble du boîter d'interrupteur

Parts List	Model #	27436	27430	27431
	Asm. Dwg. #	93026-01	93026-04	93026-05
	Finish	White	Antique Brass	Brushed Nickel
Item Name	**Qnty**	**Part #**	**Part #**	**Part #**
* Hanging System Kit	1	94330-03	94330-05	94330-09
Ceiling Plate				
Canopy				
Canopy Trim Ring				
Hanger Ball / Downrod Assembly				
Setscrew				
Low Profile Washer				
Canopy Screw				
Wood Screw 1.5"				
Wood Screw 3"				
Flat Washer				
Mounting Isolator				
* Screw, Low Profile				
Light Kit Assembly	1	99680-03	99680-05	99680-09
Blade Iron Set	1	92803-07	92803-07	92803-07
Blade Set	1	75516-30	75516-28	75516-35
Screw, Blade Iron Armature	11	63755-05	63755-05	63755-05
Hardware Kit	1	93026-00-860	93026-00-863	93026-00-864
Blade Grommet				
Blade Assembly Screw				
Screw, Machine, 6-32				
Wire Connector				
Screw, Switch Housing Assembly				
Balancing Kit	1	65666-01	65666-01	65666-01
Switch Housing, Lower, Alternate	2	93598-01	93598-01	93598-01
Switch Housing Cover, Alternate	1	73853-01	73853-01	73853-01
Switch Housing Cover, Alternate	1	73854-01	73854-01	73854-01
Thumb Screw	10	03077-08	03077-08	03077-08
Globe/Shade	3	73560-14	73560-13	84884-03